

INSTALLATION INSTRUCTIONS Always follow the wood manufacturer's recommendations for subfloor moisture, subfloor levelness, expansion space and acclimation requirements. All subfloors must be smooth within 1/8" in 6', or 3/16" in 10' and structurally sound, clean, dry, smooth, and free of dust, wax, oils, paint, curing agents and any other contaminants that would interfere with a good bond. Scan the QR Code for detailed instructions.

VERY IMPORTANT Select the correct trowel for the wood you are installing. Using the incorrect trowel will void the warranty. This is a wet-lay adhesive. Do not spread more adhesive than can be covered within 30-45 minutes. Moisture cures this adhesive. It is the installer's responsibility to gauge the rate of cure as it can vary greatly, depending on ambient humidity. Always refer to the wood flooring manufacturer for subfloor moisture requirements and testing procedures before proceeding with installation. Do not use if the substrate exceeds the wood flooring manufacturer's moisture limits or 3lbs. Good transfer of the adhesive to the wood is critical. Periodically, pull back a board that has just been installed, and make sure there is 100% adhesive transfer to the board. HVAC must be operational. Also approved for use with rubber tile, rubber stair treads & nosings and recycled rubber flooring. Most applications require a 1/8" square notched trowel. No maintenance is required.

TROWELS AND COVERAGE		
Floor Product	Trowel	Coverage
Engineered and Cork up to 7" wide and up to 5/8" thick. Solid and Bamboo up to 3" wide and up to 1/2" thick.		50-55 ft ² /gal.
	3/16" x 1/4" x 1/2" V NOTCH	
Wood Flooring over 3" wide and up to 3/4" thick		30-40 ft ² /gal.
	1/4" x 1/4" x 1/4" SQ NOTCH	
Finger Block Parquet, Recycled Rubber Flooring and Cork Underlayment		70-80 ft ² /gal.
	1/8" x 1/8" x 1/8" SQ NOTCH	

BondWise™

ADHESIVES UR-004

URETHANE

- ▶ **LOW SOLVENT/VOC ADHESIVE**
- ▶ **EASY TROWEL APPLICATION**
- ▶ **SUPERIOR NON-SLIP CAPABILITY**

CONTRACTOR PREFERRED

4 GALLONS



UR-004 is a moisture cure urethane adhesive formulated for fast grab to prevent boards from slipping in wet adhesive with a tensile strength that remains elastic and elongates to prevent breaking the bond to the subfloor under natural wood movement, making it perfect to accommodate the exotic woods that expand and contract with changes in humidity. The low slump formulation allows trowel ridges to hold form reducing hollow spots, repair and expense. Suitable for installing all types of hardwood flooring designated as "glue-down" by the wood manufacturer. Low in odor. VOC compliant.

RESTRICTIONS For interior installations only. Do not install over adhesive residue including cutback. Do not install when ambient temperature is not between 60°F & 95°F. Do not install when ambient relative humidity is above 65%. It is the sole responsibility of the installer to determine the suitability and compatibility of the adhesive for the user's intended use.

CLEAN-UP Remove the adhesive from the wood floor surface as soon as possible before the adhesive dries. Use a soft cloth and Urethane Adhesive Remover (UAR) carefully to not harm the finish. Clean equipment and tools with UAR while the adhesive is still wet.

CAUTION Urethane Adhesive Remover is flammable. Read and follow all precautions on container label.

Wise Products, LLC
635 Old Hickory Blvd. Nashville, TN 37138
Phone: (615) 847-2919
Internet: www.wiseflooringproducts.com
Limited Warranty

