

SoundWise™

FOR RESIDENTIAL OR COMMERCIAL PROJECTS

PBS1560

POLYETHYLENE PERIMETER BARRIER STRIP

APPROVED SUBSTRATES

Cured Concrete
APA Grade Plywood

APA Approved Interior Subfloors
OSB

- # PERIMETER EXPANSION JOINTS
- # SOUND ABATEMENT
- # EASY INSTALLATION

"Working with ExxonMobil and use of their performance polymers has been key to the successful development of this unique product."

Ron Wise – Owner, Wise Manufacturing



ExxonMobil

Vistamaxx™
Performance Polymers

Installation Instructions

Floor Installation-

1. Clean, sweep or vacuum floor of all debris.
2. Check that the floor is clean, dry and level.
3. Place PBS vertically against the perimeter of floor.
4. Lay flooring to the PBS.
5. Check that 1/4" expansion joint around the perimeter of the floor has been accomplished.

Installation for Sound Abatement-

1. Clean, sweep or vacuum floor of all debris.
2. Remove any baseboards from the perimeter of the flooring.
3. Place PBS vertically against the perimeter of floor.
4. Reinstall the baseboards.



Find Out More About Our Products

support@wiseflooringproducts.com

www.wiseflooringproducts.com
(615) 847-2919



PHYSICAL CHARACTERISTICS

MATERIAL	DENSITY	THICKNESS	WARRANTY	Width	JOINING SYSTEM
Polyethylene Foam	1.5lbs/ft ³	.25in	Limited 1 year	4"	NONE

4" x 125' (41.66 ft²)